

IMD Model 750-2CS

v23MAR2018

**Note: Sensitivity and Length Rejection settings located inside of top access panel.*

- >Ensure all counter setting are on the appropriate set points for the crop being counted
- >Carefully pour the 1,000 seed calibration sample of the crop being counted into seed counter bowl
- >Start counter and run until all seeds have been counted
- >Record number of seeds as displayed on counter display and any additional seeds remaining in bowl
- >Calibration count should not vary more than ± 2 seeds from the 1,000 seed calibration sample
- >If count is not within the tolerance, check settings, clean appropriate areas of the counter
- >Rerun calibration sample up to 3 times to confirmed that the counter may not be working appropriately
- >If count is not within the ± 2 seed tolerance then manually count calibration sample to confirm 1,000 seeds
- >If calibration sample does not contain 1000 seeds, adjust as needed by adding or removing seeds
- >If calibration sample is correct, adjust speed and/or sensitivity settings until ± 2 seed tolerance is obtained
- >If seed counter continues to fail calibration check, do not use until counter has been repaired and then verified using the 1,000 seed calibration sample

IMD Model 750-2CS

v23MAR2018

***Note: Sensitivity and Length Rejection settings located inside of top access panel.**

- >Ensure all counter setting are on the appropriate set points for the crop being counted
- >Carefully pour the 1,000 seed calibration sample of the crop being counted into seed counter bowl
- >Start counter and run until all seeds have been counted
- >Record number of seeds as displayed on counter display and any additional seeds remaining in bowl
- >Calibration count should not vary more than ± 2 seeds from the 1,000 seed calibration sample
- >If count is not within the tolerance, check settings, clean appropriate areas of the counter
- >Rerun calibration sample up to 3 times to confirmed that the counter may not be working appropriately
- >If count is not within the ± 2 seed tolerance then manually count calibration sample to confirm 1,000 seeds
- >If calibration sample does not contain 1000 seeds, adjust as needed by adding or removing seeds
- >If calibration sample is correct, adjust speed and/or sensitivity settings until ± 2 seed tolerance is obtained
- >If seed counter continues to fail calibration check, do not use until counter has been repaired and then verified using the 1,000 seed calibration sample

IMD Model 750-2CS

v23MAR2018

***Note: Sensitivity and Length Rejection settings located inside of top access panel.**

- >Ensure all counter setting are on the appropriate set points for the crop being counted
- >Carefully pour the 1,000 seed calibration sample of the crop being counted into seed counter bowl
- >Start counter and run until all seeds have been counted
- >Record number of seeds as displayed on counter display and any additional seeds remaining in bowl
- >Calibration count should not vary more than ± 2 seeds from the 1,000 seed calibration sample
- >If count is not within the tolerance, check settings, clean appropriate areas of the counter
- >Rerun calibration sample up to 3 times to confirmed that the counter may not be working appropriately
- >If count is not within the ± 2 seed tolerance then manually count calibration sample to confirm 1,000 seeds
- >If calibration sample does not contain 1000 seeds, adjust as needed by adding or removing seeds
- >If calibration sample is correct, adjust speed and/or sensitivity settings until ± 2 seed tolerance is obtained
- >If seed counter continues to fail calibration check, do not use until counter has been repaired and then verified using the 1,000 seed calibration sample